


C/S GROUP Model: *FR-260C ACCENT RAIL*

23G

NOTE: MATERIAL MUST REACH 65°F MIN TO 75°F MAX 24 HOURS PRIOR TO INSTALLATION. THIS IS ESSENTIAL TO MINIMIZE EXPANSION AND CONTRACTION OF THE MATERIAL.



NOTES:


1. ALL DIMENSIONS ARE TYPICAL
2. FOR DRYWALL/PLASTER WALL CONSTRUCTION, RECOMMENDED FASTENERS REQUIRE ENGAGEMENT INTO METAL/WOOD STUDS TO MAINTAIN MAXIMUM PULL-OUT STRENGTH

WALL CONDITION	SPECIFIED FASTENER	DRILL DIAMETERS		C/S PART NUMBER
		WALL	RETAINER	
STEEL STUD/GYPSUM WALL	#6 x 1-5/8" BUGLE HD. S.M.S.	N/A	7/64"	90H079002
CONCRETE/CONC. BLOCK	AF-6 ALLIGATOR ANCHOR #10 X 1-1/2" PHILLIPS PAN HD. SMS	1/4"	9/32"	90H039004 90H189002
WOOD STUD/GYPSUM WALL	#6 x 1-5/8" BUGLE HD. S.M.S.	N/A	7/64"	90H079002


INSTALLATION INSTRUCTIONS

FR-260C ACCENT RAIL

23G



1. ESTABLISH ACCENT RAIL HEIGHT ABOVE FINISH FLOOR. DEDUCT 1-15/32" (37.3mm) AND SNAP A CHALK LINE AT THAT HEIGHT. THIS MARKS THE LOCATION OF THE FASTENERS FOR THE VINYL RETAINER.
2. CUT THE CONTINUOUS RETAINER TO LENGTH, USING THE REQUIRED DEDUCTIONS AS NOTED. (SEE REVERSE) DRILL CLEARANCE HOLES FOR THE REQUIRED FASTENER AT 16" (406.4mm) O. C., AT THE V-GROOVE, ALONG THE RETAINER LENGTH.
3. USING THE VINYL RETAINER AS A TEMPLATE, MARK THE FASTENER LOCATIONS ALONG THE CHALK LINE AND DRILL HOLE DIAMETER (AS REQUIRED) AT THE PROPER LOCATIONS. SEE NOTE 2 REVERSE.
4. INSTALL EACH SECTION OF RETAINER, IN SUCCESSION, USING THE APPROPRIATE FASTENER HARDWARE. USE A LEVEL TO ENSURE THAT RETAINER IS PLUMB.
5. MITER ONE END OF THE ACROVYN AT 45°, AS REQUIRED AND CUT THE COVER TO LENGTH [RETAINER LENGTH PLUS 1/8" (3.18mm)]. THEN PROVIDE A 45° MITER 1/2" FROM THE REAR OF THE ACROVYN COVER. SEE DETAIL ABOVE, AT END CAP.
6. ATTACH EACH END CAP BY APPLYING A SMALL AMOUNT OF INSTANT ADHESIVE ALONG THE INSIDE EDGE OF THE ACROVYN COVER AND ON EACH TAB OF THE RIGHT OR LEFT HAND END CAP. ALIGN THE END CAP WITH THE END OF THE ACROVYN COVER AND SECURE INTO THE PROPER POSITION. REMOVE ANY EXCESS ADHESIVE, IMMEDIATELY, WITH A MILD SOLVENT SUCH AS ISOPROPYL ALCOHOL.
7. PEEL THE PROTECTIVE COVERING FROM THE ADHESIVE STRIP LOCATED ON THE REAR OF THE ACROVYN COVER. SLIDE THE TOP REAR PORTION OF THE COVER INTO THE CHANNEL, BETWEEN THE TOP OF THE RETAINER AND WALL SURFACE. ALIGN THE COVER WITH THE TOP OF THE RETAINER AND, USING A SLIGHT ROTATING MOVEMENT, SECURE THE ACROVYN COVER INTO POSITION AT THE RECEIVER SLOT LOCATED ON THE BOTTOM OF THE RETAINER. USING A SOFT CLEAN CLOTH, RUB THE SURFACE OF THE ACROVYN COVER, WITH MEDIUM PRESSURE, TO ENSURE MAXIMUM ADHESION OF THE COVER TO THE RETAINER.



CONSTRUCTION SPECIALTIES, INC.
AND/OR
DecoGard Products, Inc.

MUNCY, PENNSYLVANIA 17756-9106
VISTA, CALIFORNIA 92083-8438
MISSISSAUGA, ONTARIO L5E 2C2

A member of the
CS GROUP
of companies

FOR FURTHER ASSISTANCE CALL 1-888-834-4455 OR FAX 570-546-5169
OR IN CANADA CALL 905-274-3611 OR FAX 905-274-6241

5/98

This document is the property of Construction Specialties, Inc. and contains CONFIDENTIAL PROPRIETARY INFORMATION that is not to be disclosed to third parties and is not to be used without approval in writing from Construction Specialties, Inc.